

Modalità di funzionamento

Nella colonna "Luminosità" è possibile controllare lo stato del ledwall.



Log	Risoluzione	m ²	Playlist pubblicata	Luminosità
	416x624	2.4	2024-04-15 12:13	100%
	416x624	2.4	2024-04-15 12:17	70%
	416x624	2.4	2024-04-15 12:15	50%
	416x624	2.4	2024-04-15 12:18	50%
	416x624	2.4	2024-04-15 12:14	70%
	416x624	2.4	2024-04-15 12:18	50%
	416x624	2.4	2024-04-15 12:16	70%
	416x624	2.4	2024-04-15 12:15	100%
	416x624	2.4	2024-04-15 12:16	100%

Cliccando sull'icona si potranno selezionare le modalità per gestire la luminosità del ledwall.

Test Ufficio A

Brightness setting

ID	Name	Manual	Setting
SGN1	Schermo	<input type="checkbox"/>	Astronomical

Astronomica: curva annuale di alba e tramonto.

Automatic brightness setting

Mode

Table

Astronomical

Day brightness %

Night brightness %

Sunrise duration

x

RESET

Sunset duration

x

Today




Tabella: schedulazione oraria.

Automatic brightness setting


Mode

Table

Astronomical


Time	Brightness		
09:00 ☉	30	+	✗
12:00 ☉	100	+	✗
18:00 ☉	80	+	✗
20:00 ☉	10	+	✗
22:00 ☉	0	+	✗

Everyday



Manuale: regolazione manuale e istantanea.

Brightness setting

ID	Name	Manual	Setting
SGN1	Schermo	<input checked="" type="checkbox"/>	 61 %

Sensore: controllo automatico tramite sensore ambientale, visibile e attivabile se installato.

Automatic brightness setting

Mode



Sensor




Table



Astronomical

Maximum brightness % starting from lux
Minimum brightness %

Response curve



Revision #6

Created 24 March 2023 15:23:17 by Alessandro

Updated 19 April 2024 09:18:12 by Alessandro